

Slim Power Relays/Relay Sockets RJ Series Plug-in Relays/SJ Series Sockets



# Compact slim power relays with high capacity


Relay sockets available with slim space-saving push-in terminals and standard screw terminals.

**IDEC CORPORATION** 

## Slim power relays **RJ Series**

## Comapct slim power relays with high capacity


RJ series slim power relays are plug-in terminal relays suitable for various applications such as control panels and machine tools.



**FAL** (D') Lloyd's Register and DNV certified. See website for details on approvals and standards.

#### High capacity


Highly conductive materials ensure stable current-carrying performance even under high currents.



Note) Comparison with equivalent competitor products (based on IDEC research, March 2023)

#### **Excellent durability**

Unique return spring structure improves durability and reliability of mechanical parts.



Note) Comparison with equivalent competitor products (based on IDEC research, March 2023)

### Wide range of variations

Bifurcated contact relays for high reliability

Applicable for loads as low as 1V DC, 100µA (reference value).


A wide range of auxiliary features such as RC circuits and diodes available.

Protects electronic components in the circuit by absorbing back EMF (surge) generated by relay coils.

#### User-friendly product design

#### Highly visible operation indicator LED

IDEC's unique light guide structure allows the status to be checked at a glance from the top surface of the relay housing.



#### Voltage can be identified by tape color

The color of the tape is different for each rated coil voltage, so the rated voltage can be easily recognized. (\*1)



\*1) The voltage is marked on the yellow tape.

## Relay sockets SJ Series

## Low-profile, space-saving sockets for RJ series relays

Push-in terminal, standard screw terminal, and finger-safe screw terminal types can be selected depending on the application.

Push-in terminal

(Push-in terminal, standard screw terminal relay sockets) See website for details on approvals and standards. Standard screw terminal


Finger-safe screw termina

termina

Time saving & efficient

#### Save up to 55% in wiring time

Wiring time reduced greatly compared with conventional screw terminals. (compared with IDEC products)



#### **Reduce maintenance work**

Push-in terminals eliminate the need for torque maintenance such as tightening of screws, because




#### High visibility

eco

#### Proven reliability

The terminal number on the socket can be clearly seen on the socket preventing incorrect wiring. Also, the safe structure of the pusher prevents the driver from directly contacting the spring.



#### Equipped with a release lever

#### Easy to remove in tight spaces

Easy to remove with fingers, even in tight spaces when mounted on a DIN rail.



#### Compact and durable slim power relay with high allowable contact current.

• RJ Series For PCB terminal types, see website. https://apac.idec.com/c/RJ\_PCB\_Series



Coil voltage

12V AC 24V AC 100-(110) V AC 110V AC 115V AC 120V AC 200-(220)V AC 220V AC 230V AC 240V AC 5V DC 6V DC 12V DC 24V DC 48V DC 100-110V DC

#### **RJ Series**

Shape	Single contact, 1-pole with forward polarity diode (with LED indicator)	Single contact	
	forward polarity diode (with LED indicator)	2-pole standard (with LED indicator )	Bifurcated contact

#### Single contact

Single contact				Package quantity:1	Coil rate	ed voltage
		1-pole (SPDT)		2-pole (DPDT)		
Туре	Part No. (Ordering No.)	Code: 🗖	Part No. (Ordering No.)	Code: 🗆	Code	Coil volt
		A12, A24, A100, A110		A12, A24, A100, A110	A12	12V AC
Standard	RJ1S-CL-□	A200, A220	BJ2S-CL-□	A200, A220	A24	24V AC
(with LED indicator)		D5, D6, D12, D24, D48	nJZO-UL-LI	D5, D6, D12, D24, D48		-
		D100		D100	A100	100-(110)
		A12, A24, A100, A110		A12, A24, A100, A110	A110	110V AC
Simple	RJ1S-C-□	A200, A220		A200, A220	A115	115V AC
(*1)		D5, D6, D12, D24, D48	RJ2S-C-□	D5, D6, D12, D24, D48	A120	120V AC
		D100		D100		
With forward polarity		D5, D6, D12, D24, D48		D5, D6, D12, D24, D48	A200	200-(220)V
diode (with LED indicator)	RJ1S-CLD-□	D100	RJ2S-CLD-□	D100	A220	220V AC
With forward ploarity	RJ1S-CD-□	D5, D6, D12, D24, D48	RJ2S-CD-□	D5, D6, D12, D24, D48	A230	230V AC
diode (*1)		D100	KJZS-GD-LL	D100	A240	240V AC
With reverse polarity diode		D5, D6, D12, D24, D48	RJ2S-CLD1-□	D5, D6, D12, D24, D48		
(with LED indicator)	KJ15-GLD1-LI	D100	KJZS-GLDI-LI	D100	D5	5V DC
With reverse polarity		D5, D6, D12, D24, D48		D5, D6, D12, D24, D48	D6	6V DC
diode (*1)	RJ1S-CD1-□	D100	RJ2S-CD1-□	D100	D12	12V DC
With RC circuit		A12, A24, A100, A110		A12, A24, A100, A110	D24	24V DC
(with LED indicator)	RJ1S-CLR-□	A200, A220	RJ2S-CLR-□	A200, A220		-
With RC circuit		A12, A24, A100, A110		A12, A24, A100, A110	D48	48V DC
(*1)	RJ1S-CR-□	A200, A220	RJ2S-CR-□	A200, A220	D100	100-110V I

\*1) Not equipped with LED indicators.

• Other coil voltages available. (A115, A120, A230, A240)

Bifurcated contact (PCB terminal)

(Refer to coil rating table) Package quantity:1

A100 and A200 are

3-rated coils.

		2-pole (DPDT bifurcated contact)
Туре	Part No. (Ordering No.)	Code: 🗆
Standard	RJ22S-CL-□	A12, A24, A100, A110, A115, A120, A200, A220, A230, A240
(with LED indicator)		D5, D6, D12, D24, D48, D100
Simple	BJ22S-C-□	A12, A24, A100, A110, A115, A120, A200, A220, A230, A240
(*2)	KJ225-6-LI	D5, D6, D12, D24, D48, D100
With forward ploarity diode (with LED indicator)	RJ22S-CLD-□	D5, D6, D12, D24, D48, D100
With forward ploarity diode (*2)	RJ22S-CD-□	D5, D6, D12, D24, D48, D100
With reverse polarity diode (with LED indicator)	RJ22S-CLD1-□	D5, D6, D12, D24, D48, D100
With reverse polarity diode (*2)	RJ22S-CD1-□	D5, D6, D12, D24, D48, D100
With RC circuit (with LED indicator)	RJ22S-CLR-□	A12, A24, A100, A110, A115, A120, A200, A220, A230, A240
With RC circuit (*2)	RJ22S-CR-□	A12, A24, A100, A110, A115, A120, A200, A220, A230, A240

\*2) Not equipped with LED indicators.

#### **Contact ratings**

Single contact

		Allowable co	ontact power		Rated load		Allowable	Allowable	Minimum		
No. of poles Contact		Resistive load Inductive load		Voltage Resistive load		Inductive load cosø=0.4 L/R=7ms	switching current	switching voltage	applicable load (*1)		
	NO contact 3000VA		1875VA AC	250V AC	12A	7.5A			5V DC		
1	side	side 360W DC	180W DC	30V DC	12A	6A	104	250V AC	100mA		
i-pole	1-pole NC contact	act 3000VA AC	3000VA AC	3000VA AC	1875VA AC	250V AC	12A	7.5A	12A	125V DC	(Reference
	side	180W DC	90W DC	30V DC	6A	3A			value)		
	NO contact	2000VA AC	1000VA AC	250V AC	8A	4A			5V DC		
0 nolo	side		120W DC	30V DC	8A	4A	8A	250V AC	10mA		
2-pole	NC contact	2000VA AC	1000VA DC	250V AC	8A	4A	оА	125V DC	(Reference		
	side	120W DC	60W DC	30V DC	4A	2A			value)		

\*1) Measured at operating frequency of 120 operations/min. Failure rate P level (reference value)

#### **Bifurcated contact**

Allowable co	Allowable contact power Rated load				Allowable	Allowable	Minimum applicable load	
Resistive load	Inductive load	Voltage	Resistive load	Inductive load cosø=0.4 L/R=7ms	switching current	switching voltage	Minimum applicable load (*2)	
250VA AC	100VA AC	250V AC	1A	0.4A	14	250V AC	1V DC	
30W DC	15W DC	30V DC 1A 0.5A		0.5A	1A	125V DC	100µA (reference value)	

\*2) Measured at operating frequency of 120 operations/min. Failure rate P level (reference value)

#### **Approval ratings**

#### Single contact

		UL ra	tings					CSA r	atings				VDE ratings			
Voltago		Resi	stive			Resistive			Inductive				Resistive		AC-15, DC-13 (*3)	
Voltage	R	J1	R	12	R	J1	R	J2	R	J1	R	J2	RJ1	RJ2	RJ1	RJ2
	NO	NC	NO	NC	NO	NC	NO	NC	NO	NC	NO	NC	NO	NO	NO	NO
250V AC	12A	6A	8A	4A	12A	12A	8A	8A	7.5A	7.5A	4A	4A	12A	8A	6A	3A
30V DC	12A	6A	8A	4A	12A	6A	8A	4A	6A	3A	4A	2A	12A	8A	2.5A	2A

Note: According to the utilization categories of IEC 60947-5-1.

#### **Bifurcated contact**

	UL ratings							VDE ratings					
	Voltage	Resistive General Use		al Use	Resistive		Inductive		General Use		Resistive		
		NO	NC	NO	NC	NO	NC	NO	NC	NO	NC	NO	NC
Г	250V AC	-	-	1A	1A	-	-	-	-	1A	1A	1A	1A
	30V DC	1A	1A	-	-	1A	1A	1A	1A	-	-	1A	1A

Note: According to the utilization categories of IEC60947-5-1.

#### **Coil rating**

			Wi	thout LED in	ndicator	٧	Vith LED in	dicator	Operating characteris	stics (against rat	ed values at 20°C)	
Coil ra	ted voltage (V)	Code □	±15%	(at 20°C)	Coil resistance $(\Omega) \pm 10\%$	±15%	(at 20°C)		operating voltage	Return voltage	Maximum allowable	Power consumption
			50Hz	60Hz	(at 20°C)	50Hz	60Hz	(at 20°C)	(initial value)	(initial value)	voltage (*5)	
	12V	A12	87.3	75.0	62.5	91.1	78.8	62.5				
	24V	A24	43.9	37.5	243	47.5	41.1	243				
	100-(110)V	A100	10.5	9.0-10.4	4470	10.3	8.8–10.2	4470				
	110V	A110	9.6	8.2	5270	9.5	8.1	5270				Approx. 1.1VA
AC	115V	A115	9.1	7.8	6030	9.0	7.7	6030	- 900/ mov 200/ min	000/ min	1 400/	(50Hz)
50/60Hz (*4)	120V	A120	8.8	7.5	6400	8.7	7.4	6400	80% max.	30% min.	140%	Approx. 0.9 to
( ")	200-(220)V	A200	5.3	4.5×5.2	17,950	5.3	4.5×5.2	17,950	_		1.2VA (60Hz)	
	220V	A220	4.8	4.1	21,530	4.8	4.1	21530				
	230V	A230	4.6	3.9	24,100	4.6	3.9	24,100				
	240V	A240	4.3	3.7	25,570	4.3	3.7	25,570				
	5V	D5	106		47.2	1	10	47.2				
	6V	D6	88	.3	67.9		92.2	67.9				
	12V	D12	44	.2	271		48.0	271	700/	100/ main	170%	Approx. 0.53
DC	24V	D24	22	.1	1080		25.7	1080	70% max.	10% min.		to 0.64W
	48V	D48	11	.0	4340		10.7	4340	]			
	100-110V	D100	5.3-5	.8	18,870	5.2	-5.7	18,870			160%	

\*4)100-(110)V and 200-(220)V are 3 rated coils.

100-(110)V: 100V AC (50/60Hz), 110V AC (60Hz)

200-(220)V: 200V AC (50/60Hz), 220V AC (60Hz) \*5) The maximum allowable voltage is the maximum value of voltage that can be applied to the relay coil and not the continuous allowable value.

#### **Characteristics**

Part No.		RJ1S	RJ2S	RJ22S				
No. of Poles	3	1-pole	2-pole	2-pole				
Contact con	figuration	SPDT contact	DPDT contact	DPDT (bifurcated contacts)				
Contact mat	terial	AgNi		AgNi (Au clad)				
Degree of P	rotection	IP40 (enclosed)						
Contact resi	istance (initial value) (*1)	50mΩ max.						
Operating ti	ime (*2)	15ms max.						
Release tim	ie (*2)	10ms max.						
Insulation re	esistance	100M $\Omega$ min. (500V DC megg	ger)					
<b>D</b> : 1 - 1 -	Between contact circuit and coil	5000V AC, 1 minute	5000V AC, 1 minute	5000V AC, 1 minute				
Dielectric strength	Between contacts of the same pole	1000V AC, 1 minute	1000V AC, 1 minute	1000V AC, 1 minute				
Suchgui	Between contacts of different poles	-	3000V AC, 1 minute	3000V AC, 1 minute				
Vibration	Operating extremes	Damage limits: 10 to 55Hz, amplitude 0.75mm						
resistance	Damage limits	Damage limits: 10 to 55Hz, amplitude 0.75mm						
Shock	Operating extremes	NO contact side: 200 m/s2,	NC contact side: 100 m/s <sup>2</sup>					
resistance	Damage limits	1000m/s <sup>2</sup>						
Electrical lif	e (rated load)	AC load: 200,000 times min. (operating frequency: 1800 DC load: 100,000 times min (operating frequency: 1800	operations per hour)	AC load: 100,000 times min. (operating frequency: 1800 operations per hour) DC load: 200,000 times min. (operating frequency: 1800 operations per hour)				
Mechanical	life (no load)	AC coil: 30 million times min (operating frequency: 18,000 DC coil: 50 million times min (operating frequency: 18,000	) operations per hour) 1.	AC coil: 10 million times min. (operating frequency: 18,000 operations per hour) DC coil: 20 million times min. (operating frequency: 18,000 operations per hour)				
Operating te	emperature (*3)	-40 to +70°C (no freezing)						
Operating h		5 to 85%RH (no condensation)						
Storage terr		-40 to +85°C (no freezing)						
Storage hun		5 to 85%RH (no condensatio	n)					
Weight (app	prox.)	19g						

• Above values are initial values.

\*1) Measured using 5V DC, 1A voltage drop method

\*2) Measured at the rated voltage (at 20°C), excluding contact bounce time. The recovery time of relays with diode is 20ms max. The recovery time of relays with RC circuit is 20ms max.
\*3) When 100% of the rated voltage is applied


All dimensions in mm.

#### Applicable socket


Turne	Part No.						
Туре	For RJ1S (1-pole)	J1S (1-pole) For RJ2S (2-pole) For RJ22					
Standard screw terminal	SJ1S-05BS	SJ2S-	05BS				
Finger-safe screw terminal	SJ1S-07L	SJ2S-	07L				
Push-in terminal	SJ1S-21L	SJ2S-	21L				

#### Dimensions

#### RJ1S




**RJ2S, RJ22S** 




#### Internal connection (Bottom View)


#### RJ1S-CL- Standard (with LED indicator)



#### RJ1S-C-□ Simple




#### RJ1S-CLD- With forward polarity diode (with LED indicator)




#### RJ1S-CD- With forward ploarity diode

(A1) -		I I
5 +	2(12) 4(11) 3(14)	
(A2)		J


#### RJ1S-CLD1-□ With reverse polarity diode (with LED indicator)




#### RJ1S-CD1- $\square$ With reverse polarity diode




#### RJ1S-CLR- With RC circuit (with LED indicator)







#### RJ1S-CR-□ With RC circuit




#### RJ2S-CL- / RJ22S-CL- Standard (with LED indicator)





RJ2S-C-□/ RJ22S-C-□ Simple



RJ2S-CLD- / RJ22S-CLD- With forward polarity diode (with LED indicator)

(A1) (A1) (A1) (A2) (A2) (A2) (A2) (A2) (A2) (A2) (A1) (A
Coil voltage 24V DC and below

$(A2)^{+}$ 7(22) 6(21) 5(24)
Coil voltage greater than 24V DC

RJ2S-CD- / RJ22S-CD- With forward polarity diode


<sup>8</sup> + 7 (22) 6 (21) 5 (24)	

RJ2S-CLD1- / RJ22S-CLD1- With reverse polarity diode (with LED indicator)


	(A1)
8 – 7(22) 6(21) 5(24)	(A2)
Coil voltage 24V DC and below	


$\begin{bmatrix} 8 & - & - & - & - & - & - & - & - & - &$
Coil voltage greater than 24V DC

#### RJ2S-CD1- / RJ22S-CD1- With reverse polarity diode



RJ2S-CLR- / RJ22S-CLR- With RC circuit (with LED indicator)





RJ2S-CR-□ / RJ22S-CR-□ With RC circuit

(A1)	
中↓	2(12) 3(11) 4(14)
(A2)	7(22) 6(21) 5(24)



#### **Characteristics (reference)**


#### **Electrical life curve** RJ1S RJ2S 500 250V AC Resistive Load 250V AC Resistive Load Life (x 10,000 operations Life (×10,000 operations) 100 30V DC resistive load (NO contact) 30V DC resistive load (NO contact) <u>30V D(</u> (NC co inductive ntact) 250V AC inductive 30V DC resistive load (NC contact) 30V DC resistive load (NO contact) 400 C resistive load (NO contact) 10 -30V DC resistive load (NC contact -30V DC inductive load (NO contact 0.1 Load Current (A) Load Current (A) Maximum operation capacity RJ2S RJ1S AC resistive load AC Load Current (A) Load Current (A) ₩ contact) inductive contact) NO contact

10 100 250 Load Voltage (V)


DC inductive

#### Characteristics (reference) Ambient temperature and coil temperature rise RJ1S


0.'












Note) When the rated coil voltage (100%) is applied. 3 rated coil is at 100% for the higher voltage. 100V AC (50Hz), 110V AC (60Hz) when 100-(110)V. 200V AC (50Hz), 220V AC (60Hz). when 100-(220)V.


0.1


10


100 250


Load Voltage (V)
















Note: The dashed lines indicate the allowable temperature rise of the coil at different ambient temperatures.


#### Safety Precautions


- Turn off the power to the product before starting installation, removal, wiring, maintenance, and inspection of the products. Failure to turn power off may cause electrical shock or fire.
- Be sure to use the product within the rated specifications. Failure to turn power off may cause electrical shock or fire.

#### Instructions

#### 1. Driving Circuit for Relays


- 1) To make sure of correct relay operation, apply rated voltage to the relay coil.
- 2) Input voltage for DC coil:
- A complete DC voltage is best for the coil power to make sure of stable operation. When using a power supply containing a ripple voltage, suppress the ripple factor within 5%. When power is supplied through a rectification circuit, relay operating characteristics, such as pickup voltage and dropout voltage, differ on the ripple factor. Connect a smoothing capacitor to check the characteristics, as shown below.






Ripple Factor (%) Emax – Emin Emean × 100% Emax = Maximum of pulsating current Emin = Minimum of pulsating current Emean = DC mean value

3) Operating the relay in sync with an AC load:



 If the relay operates in sync with the relay contact, the relay life may be reduced. If this is the case, select a relay in consideration of the required reliability for the load, or make the relay turn on and off irrespective of the AC power phase or near the point where the AC phase crosses zero voltage.


- For wiring, use wires of proper size to meet voltage and current requirements. Tighten the terminal screws to the recommended tightening torque.
- 4) Leakage current while relay is off:



When driving an element at the same time as the relay operation, special consideration is needed for the circuit design. As shown in the incorrect circuit below, leakage current (lo) flows through the relay coil while the relay is off. Leakage current causes the coil release failure or adversely affects the vibration resistance and shock resistance.

Design a circuit as shown in the correct example.

- 5) Surge suppression for transistor driving circuits:
  - When the relay coil is turned off, a high-voltage pulse is generated, causing the transistor to deteriorate and sometimes to break. Be sure to connect a diode to suppress the counter electromotive force. Then, the coil release time becomes slightly longer. To shorten the coil release time, connect a Zener diode between the collector and emitter of the controlling transistor. Select a Zener diode with a Zener voltage slightly higher than the power voltage.



#### Instructions

#### 2. Protection for relay contacts

- The contact ratings show maximum values. Make sure that these values are not exceeded even momentarily. When an inrush current flows through the load, the contact may become welded. If this is the case, connect a contact protection circuit, such as a current limiting resistor.
- 2. Contact protection circuit

When switching an inductive load, arcing causes carbides to form on the contacts, resulting in increased contact resistance. In consideration of contact reliability, contact life, and noise suppression, the use of a surge absorbing circuit is recommended. Note that the release time of the load becomes slightly longer. Check the operation using an actual load.

Incorrect use of a contact protection circuit will adversely affect switching characteristics. Typical examples of contact protection circuits are shown in the following table:

RC	Power C R Ind. Load	This protection circuit can be used when the load impedance is smaller than the RC impedance in an AC load power circuit. R: Resistor of approximately the same resistance value as the load C: 0.1 to 1 $\mu$ F
	Power R Ind. Load	This protection circuit can be used for both AC and DC load power circuits. R: Resistor of approximately the same resistance value as the load C: 0.1 to 1 $\mu F$
Diode	Power D Ind. Load	This protection circuit can be used for DC load power circuits. Use a diode with the following ratings. Reverse withstand voltage: Power voltage of the load circuit × 10 Forward current: More than the load current
Varistor	Varistor Power	This protection circuit can be used for both AC and DC load power circuits. For a best result, when using on a power voltage of 24 to 48V AC/DC, connect a varistor across the load. When using on a power voltage of 100 to 240V AC/DC, connect a varistor across the contacts.

#### 3. Do not use a contact protection circuit as shown below.

Power Load	This protection circuit is very effective in arc suppression when opening the contacts. But, the capacitor is charged while the contacts are opened. When the contacts are closed, the capacitor is discharged through the contacts, increasing the possibility of contact welding.
C Load	This protection circuit is very effective in arc suppression when opening the contacts. But, when the contacts are closed, a current flows to charge the capacitor, causing contact welding.

Generally, switching a DC inductive load is more difficult than switching a DC resistive load. Using an appropriate arc suppressor will improve the switching characteristics of a DC inductive load.

#### 3. Relay coil tape color

The color of the tape wrapped around the coil is different for each coil rated voltage. (Yellow tape shows voltage)

Coil voltage	Coil color
12V AC	yellow
24V AC	white
100-(110)V AC	yellow
110V AC	Clear
115V AC	yellow
120V AC	S (Blue)
200-(220)V AC	yellow
220V AC	(black)
230V AC	yellow
240V AC	red
5V DC	yellow
6V DC	yellow
12V DC	yellow
24V DC	G (Green)
48V DC	yellow
DC100-110V	yellow

#### 4. Other precautions

1) General notice

- To maintain the initial performance, do not drop or provide shock to the relay.
- The relay cover cannot be removed from the base during normal operation. To maintain the initial characteristics, do not remove the relay cover.
- Use the relay in environments free from condensation, dust, sulfur dioxide (S0<sub>2</sub>), and hydrogen sulfide (H<sub>2</sub>S).
- Ensure that the coil applied voltage does not exceed the maximum allowable voltage and is applied continuously.
- 2) Connecting outputs to electronic circuits

When the output is connected to a load which responds very quickly, such as an electronic circuit, contact bouncing causes incorrect operation of the load. Take the following measures into consideration.

- (a) Connect an integration circuit.
- (b) Suppress the pulse voltage due to bouncing within the noise margin of the load.
- Approved ratings may differ from the product ratings specified by IDEC depending on the certification organizations and local conditions.
- Do not use relays in the vicinity of he strong magnetic field as this may affect relay operation.
  - The type with DC diode has + polarity.
  - The surge absorbing element of surge absorbing type (DC: with diode, AC: with CR circuit) is added to absorb reverse voltage of the relay coil. If an excessive surge voltage is applied externally, the surge absorbing element may be destroyed; therefore, take separate measures to absorb the surge.

## SJ Series Relay Sockets

Low-profile, space-saving sockets for RJ series relays. Equipped with a release lever.

SJ series	1		Package quantity: 1
Shape			
	Push-in terminal (2-pole)	Standard screw terminal (1-pole	) Finger-safe screw terminal (1-pole)
Туре	1 pole		2-pole
туре	Part No.		Part No.
Push-in terminal	SJ1S-21L		SJ2S-21L
Standard screw terminal	SJ1S-05BS		SJ2S-05BS
Finger-safe screw terminal	SJ1S-07L		SJ2S-07L


•Release levers are supplied with the sockets.

#### **Ratings / Specifications**

Part No.		SJ1S-21L	SJ2S-21L	SJ1S-05BS	SJ2S-05BS	SJ1S-07L	SJ2S-07L		
Rated cont	ed continuous current (*1) 12A 8A		8A	12A	8A	12A	8A		
Rated insu	lation voltage	300V AC/DC (*2)	•	250V AC/DC					
Connectable wire		Solid wire, stranded wire: 0.14 to 1.5mm²(AWG26 to Stranded wire with ferrule 0.5 to 1.5mm², AWG20 to Stranded wire with ferrule 0.14 to 1.0mm², AWG26 to	Max. 2mm <sup>2</sup>						
Recomme	nded tightening torque		-		1.0N-m				
Screw tern	ninal shape		_	M3 Phillips scr	ew (Self-lifting)				
Insulation	resistance	100MΩ min. (500V DC me	gger)						
	Between live and dead metal parts	2500V AC, 1 minute		2000V AC, 1 minute					
Dielectric	Between contact and coil		4000V AC, 1 minute						
strength	Between contacts of the same pole		1000V AC, 1 minute						
	Between contacts of different poles	2500V AC, 1 minute	3000V AC, 1 minute						
Vibration resistance	Damage limits	Damage limits: 10 to 55Hz	, amplitude 1.5mm						
Shock resi	stance (damage limits)	50G (when using release le	ever)	100G (when using release lever)					
	Operating temperature	-40 to +70°C (no freezing)							
Standard	Operating humidity	5 to 85%RH (no condensation)							
operating conditions	Storage temperature	-40 to +70°C (no freezing)		-55 to +85°C (no freezing)					
	Storage humidity	5 to 85%RH (no condensat	tion)						
Degree of	protection (screw terminal)		– IP20 (IEC 60529)						
Weight (ap	prox.)	35g	43g	27g	30g	30g	34g		

\*1) See "Continuous current" on the next page before use.\*2) When RF2S forced guide relay is used, the voltage is 150V AC/DC.

#### **Continous current**



#### Applicable relays

	1-ро	le	2-pole			
Туре	Socket Part No.	Applicable relays	Socket Part No.	Applicable relays		
Push-in terminal	SJ1S-21L		SJ2S-21L			
Standard screw terminal	SJ1S-05BS	RJ1S	SJ2S-05BS	RJ2S RJ22S RF2S		
Finger-safe screw terminal	SJ1S-07L		SJ2S-07L			

• For information on RF2 forced guided relays, see website.



#### Accessories

#### Standard screw terminal

Check the current value of the relay to be mounted and use the current value listed in the table below.

F	Part No.	SJ1S-05BS		SJ1S-07L		SJ2S-05BS			SJ2S-07L					
Max. operating temperature		70°C 55°C 40°C		70°C	55°C	40°C	70°C	55°C	40°C	70°C	55°C	40°C		
Single mount		12A		2A		12A 8		12A		8A		8A		
Close	DC Relays When mounted	Vhen 12A 10A 12A		2A	8A			6A (*5)	7A (*3)					
Close mount	When mounting AC relays	_ (*1)	12	2A	_ (*2)	11A (*1)	12A	_ (*4)	8	A	_ (*5)	7A (*3)	8A	

\*1) "12A" when there is a distance of 5mm min. from adjacent sockets.

\*2) "12A" when there is a distance of 10mm min. from adjacent sockets.

\*3) "8A" when there is a distance of 5mm min. from adjacent sockets.


\*4) "8A" when there is a distance of 10mm min. from adjacent sockets.

\*5) "8A" when there is a distance of 15mm min. from adjacent sockets.

#### Applicable crimping terminals

All dimensions in mm.

When ordering, specfiy the Ordering No.



Note:Ring crimping terminals cannot be used for finger-safe screw terminals.

	Туре	Shape	Materials	Part No.	Ordering No.	Package quantity	Applicable model	Remarks	
			Plastic (white)	SJ9Z-P2100W	SJ9Z-P2100W	10	SJ1S-21L SJ2S-21L	-	
Marking plate				SJ9Z-PW	SJ9Z-PWPN10		SJ1S-07L SJ2S-07L	15.2 98 97 97 97 97 97 97 97 97 97 97	
	For push-in terminal		Bronze (tin-plated) Coating: PBT	SU9Z-J2102A	SU9Z-J2102A	10	SJ1S-21L SJ2S-21L	The A2 terminal of the coil is cross-connected. Rated continuous current: 2A	
(*6)	For 8 sockets	ň	Brass Coating: PBT	SJ9Z-JF8S	SJ9Z-JF8S	10	SJ1S-05BS SJ2S-05BS	Terminal centers: 15.8mm Rated continuous current : 12A	
	For two sockets	- X -	Brass (nickel plated) Coating: Polypropylene	SJ9Z-JF2	SJ9Z-JF2PN10		SJ1S-07L SJ2S-07L		
	For 5 sockets			SJ9Z-JF5	SJ9Z-JF5PN10			Terminal centers: 15.5mm Rated continuous current : 12A	
	For 8 sockets			SJ9Z-JF8	SJ9Z-JF8PN10				
	For 10 sockets			SJ9Z-JF10	SJ9Z-JF10PN10				

\*6) Ensure that the total current to the jumper does not exceed the maximum current.

Туре	Shape	Materials	Part No.	Ordering No.	Package quantity	Applicable model	Remarks
DIN rail		Aluminum	BAA1000	BAA1000PN10	1 (10 pcs)		Length: 1m Width : 35mm Weight: Approx. 200g
End clip		Metal (Steel, zinc plated)	BNL6	BNL6PN10	1 (10 pcs)	SJ1S-21L SJ2S-21L SJ1S-05BS SJ2S-05BS SJ1S-07L SJ2S-07L	Weight: Approx. 15g Be sure to use an end clip to fasten multiple relay sockets on a DIN rail.
DIN rail spacer		Plastic (Black)	SA-406B	SA-406B	1		Thickness: 5mm Used for adjusting the spacing between sockets mounted on a DIN rail.
Ovinanian taal	4		S3TL-CR04T	S3TL-CR04T	1		Applicable ferrule:
Crimping tool	-	_	S3TL-CR06D	S3TL-CR06D		SJ1S-21L	With/without insulated cover
Flat blade screwdriver		-	S3TL-D04-25-75	S3TL-D04-25-75	1	SJ2S-21L	Blade size a b c Blade size a: 0.4mm b: 2.5mm c: 75mm

- For wires/ferrules compatible with Push-in terminal sockets, see p15 "Applicable wires".


#### Maintenance parts


When ordering, specfiy the Ordering No.

Туре	Shape	Materials	Part No.	Ordering No.	Package quantity	Applicable model	Remarks
Release lever		Plastic	SJ9Z-C21R	SJ9Z-C21R	10	SJ1S-21L SJ2S-21L	
Release lever		Plastic	SJ9Z-CS	SJ9Z-CS	10	SJ1S-05BS SJ2S-05BS	
Release Lever (marking plate attachable)		Plastic	SJ9Z-CM	SJ9Z-CMPN05	1 (5 pcs)	SJ1S-07L SJ2S-07L	When the marking plate is not used on the release lever

#### Dimensions

SJ1S-21L






Π


5

SJ2S-21L




#### All dimensions in mm.

Terminal arrangement




Note: Figures in parentheses ( ) are NEMA notations.




ति।






(TOP VIEW)



SJ2S-07L M3 terminal screw 00 1000 M<u>ee</u> 15.5 A Salr ĥ 9.5 29.7 E 4.3 71 ® (A2) 6 0 0 (24) <u>(14)</u> 0.9 f 1) (A1) 2)2 (TOP VIEW)



#### A Safety Precautions

- Turn off the power to the product before starting installation, removal, wiring, maintenance, and inspection of the products. Failure to turn power off may cause electrical shock or fire hazard.
- Use wires of the proper size to meet the voltage and current requirements.
- Make sure that relay and output equipment are wired correctly. Incorrect wiring causes overheating, resulting in a possible fire hazard.

#### Instructions (Push-in terminal socket)

#### Applicable wire

When wiring, use the applicable wires shown below.

#### Applicable wires and specifications

Applicable wire (stranded wire, solid wire)	0.14 to 1.5mm <sup>2</sup> (AWG16 to 26)
Wire strip length (*1)	10 to 11mm

\*1) Strip the sheath of the wire 10 to 11mm from the end. When using a ferrule, refer to "Wire size and recommended ferrules'



Note: Make sure that the stranded wires do not loosen when using wiring without ferrules.

#### Wire size and recommended ferrules

#### Ferrule terminals without insulation covers

Applicable wire (stranded wire, solid wire)		Wire strip length (*1)	Part No.	Ordering No.
(AWG)	mm <sup>2</sup>			
26	0.14	10 to 11mm	S3TL-F014-12WC	S3TL-F014-12WC
24	0.25	10 to 11mm	S3TL-H025-12WJ	S3TL-H025-12WJ
22	0.34	10 to 11mm	S3TL-H034-12WT	S3TL-H034-12WT
20	0.50	10 to 11mm	S3TL-H05-14WA	S3TL-H05-14WA
20		12 to 13mm	S3TL-H05-16WA	S3TL-H05-16WA
18	0.75	10 to 11mm	S3TL-H075-14WW	S3TL-H075-14WW
10		12 to 13mm	S3TL-H075-16WW	S3TL-H075-16WW
18	1.00	10 to 11mm	S3TL-H10-14WY	S3TL-H10-14WY
10		12 to 13mm	S3TL-H10-16WY	S3TL-H10-16WY

#### Prevent metal fragments and pieces of wire from dropping inside the socket. Ingress of such fragments and chips may cause fire hazard, damage, or malfunction.

#### Inserting the wire

Stranded wires with ferrules or solid wire

1) Insert the wire to the back of the wire port.

Wiring is complete. Pull the wire tightly to make sure that the wire does not pull out from the socket.



Stranded wire

- 1) Push the pusher (orange button) uisng a flat blade screwdriver.
- 2) Insert the wire fully in the wiring port while pressing the pusher.
- 3) Release the flat blade screwdriver. Wiring is complete. Pull the wire
- tightly to make sure that the wire does not pull out from the socket.



#### Removing the wire

1) Push the pusher using a flat blade screwdriver.

- 2) Pull out the wire while pressing the pusher.
- 3) Release the flat blade screwdriver.



Be sure to read the instruction manual carefully before performing installation, wiring, or maintenance work.

- Push-in terminal ------https://product.idec.com/?product=SJ2S-21L
- Standard screw terminal 1-pole SJ1S-05BS ------ https://product.idec.com/?product=SJ1S-05BS
- Standard screw terminal 2-pole SJ2S-05B------https://product.idec.com/?product=SJ2S-05BS
- Finger safe screw terminal 1-pole SJ1S-07L-----https://product.idec.com/?product=SJ1S-07L
- Finger safe screw terminal 2-pole SJ2S-07L-----https://product.idec.com/?product=SJ2S-07L







1-pole



Finger-safe terminal screw 1-pole Finger-safe terminal screw 2-pole

IDEC

#### **Ordering Terms and Conditions**

#### Thank you for using IDEC Products.

By purchasing products listed in our catalogs, datasheets, and the like (hereinafter referred to as "Catalogs") you agree to be bound by these terms and conditions. Please read and agree to the terms and conditions before placing your order.

#### 1. Notes on contents of Catalogs

(1) Rated values, performance values, and specification values of IDEC products listed in this Catalog are values acquired under respective conditions in independent testing, and do not guarantee values gained in combined conditions.

Also, durability varies depending on the usage environment and usage conditions.

- (2) Reference data and reference values listed in Catalogs are for reference purposes only, and do not guarantee that the product will always operate appropriately in that range.
- (3) The specifications / appearance and accessories of IDEC products listed in Catalogs are subject to change or termination of sales without notice, for improvement or other reasons.
- (4) The content of Catalogs is subject to change without notice.

#### 2. Note on applications

- (1) If using IDEC products in combination with other products, confirm the applicable laws / regulations and standards. Also, confirm that IDEC products are compatible with your systems, machines, devices, and the like by using under the actual conditions. IDEC shall bear no
- liability whatsoever regarding the compatibility with IDEC products.
  (2) The usage examples and application examples listed in Catalogs are for reference purposes only. Therefore, when introducing a product, confirm the performance and safety of the instruments, devices, and the like before use. Furthermore, regarding these examples, IDEC does not grant license to use IDEC products to you, and IDEC offers no warranties regarding the ownership of intellectual property rights of non-infringement upon the intellectual property rights.
- (3) When using IDEC products, be cautious when implementing the following.
   i. Use of IDEC products with sufficient allowance for rating and performance
  - Safety design, including redundant design and malfunction prevention design that prevents other danger and damage even in the event that an IDEC product fails
  - Wiring and installation that ensures the IDEC product used in your system, machine, device, or the like can perform and function according to its specifications
- (4) Continuing to use an IDEC product even after the performance has deteriorated can result in abnormal heat, smoke, fires, and the like due to insulation deterioration or the like. Perform periodic maintenance for IDEC products and the systems, machines, devices, and the like in which they are used.
- (5) IDEC products are developed and manufactured as general-purpose products for general industrial products. They are not intended for use in the following applications, and in the event that you use an IDEC product for these applications, unless otherwise agreed upon between you and IDEC, IDEC shall provide no guarantees whatsoever regarding IDEC products.
  - i. Use in applications that require a high degree of safety, including nuclear power control equipment, transportation equipment (railroads / airplanes / ships / vehicles / vehicle instruments, etc.), equipment for use in outer space, elevating equipment, medical instruments, safety devices, or any other equipment, instruments, or the like that could endanger life or human health
  - Use in applications that require a high degree of reliability, such as provision systems for gas / waterworks / electricity, etc., systems that operate continuously for 24 hours, and settlement systems
  - iii. Use in applications where the product may be handled or used deviating from the specifications or conditions / environment listed in the Catalogs, such as equipment used outdoors or applications in environments subject to chemical pollution or electromagnetic interference If you would like to use IDEC products in the above applications, be sure to consult with an IDEC sales representative.

#### 3. Inspections

We ask that you implement inspections for IDEC products you purchase without delay, as well as thoroughly keep in mind management/maintenance regarding handling of the product before and during the inspection.

#### 4. Warranty

(1) Warranty period

The warranty period for IDEC products shall be one (1) year after purchase or delivery to the specified location. However, this shall not apply in cases where there is a different specification in the Catalogs or there is another agreement in place between you and IDEC.

#### (2) Warranty scope

Should a failure occur in an IDEC product during the above warranty period for reasons attributable to IDEC, then IDEC shall replace or repair that product, free of charge, at the purchase location / delivery location of the product, or an IDEC service base. However, failures caused by the following reasons shall be deemed outside the scope of this warranty.

- i. The product was handled or used deviating from the conditions /  $\ensuremath{\mathsf{environment}}$  listed in the Catalogs
- ii. The failure was caused by reasons other than an IDEC product
- iii. Modification or repair was performed by a party other than IDEC
- iv. The failure was caused by a software program of a party other than  $\ensuremath{\mathsf{IDEC}}$
- v. The product was used outside of its original purpose
- vi. Replacement of maintenance parts, installation of accessories, or the like was not performed properly in accordance with the user's manual and Catalogs

vii. The failure could not have been predicted with the scientific and technical standards at the time when the product was shipped from  $\ensuremath{\mathsf{IDEC}}$ 

- viii. The failure was due to other causes not attributable to IDEC (including cases of force majeure such as natural disasters and other disasters)
- Furthermore, the warranty described here refers to a warranty on the IDEC product as a unit, and damages induced by the failure of an IDEC product are excluded from this warranty.

#### 5. Limitation of liability

The warranty listed in this Agreement is the full and complete warranty for IDEC products, and IDEC shall bear no liability whatsoever regarding special damages, indirect damages, incidental damages, or passive damages that occurred due to an IDEC product.

#### 6. Service scope

The prices of IDEC products do not include the cost of services, such as dispatching technicians. Therefore, separate fees are required in the following cases.

- Instructions for installation / adjustment and accompaniment at test operation (including creating application software and testing operation, etc.)
- (2) Maintenance inspections, adjustments, and repairs
- (3) Technical instructions and technical training
- (4) Product tests or inspections specified by you

The above content assumes transactions and usage within your region. Please consult with an IDEC sales representative regarding transactions and usage outside of your region. Also, IDEC provides no guarantees whatsoever regarding IDEC products sold outside your region.

## **IDEC CORPORATION**

Head Office 6-64, Nishi-Miyahara-2-Chome, Yodogawa-ku, Osaka 532-0004, Japan

USA	IDEC Corporation	Singapore	IDEC Izumi Asia Pte. Ltd.
EMEA	APEM SAS	Thailand	IDEC Asia (Thailand) Co., Ltd.
		India	IDEC Controls India Private Ltd.

Specifications and other descriptions in this brochure are subject to change without notice. Information in this brochure is current as of October 2023. 2023 IDEC Corporation, All Rights Reserved. 
 China
 IDEC (Shanghai) Corporation

 IDEC Izumi (H.K.) Co., Ltd.

 Taiwan

 IDEC Taiwan Corporation

Japan IDEC Corporation



🖵 www.idec.com